


<b>Last Modified:</b> 9-13-2007		1.6 R
<b>Service Category:</b> Vehicle Interior	<b>Section:</b> Theft Deterrent/Keyless Entry	
<b>Model Year:</b> 2008	<b>Model:</b> FJ Cruiser	<b>Doc ID:</b> RM00000289L00BX
<b>Title:</b> ENGINE IMMOBILISER: ENGINE IMMOBILISER SYSTEM: PARTS LOCATION (2008 FJ Cruiser)		

## PARTS LOCATION

## ILLUSTRATION




NO.2 ENJINE ROOM RERAY BLOCK  
- ECU-B FUSE



FRONT DOOR COURTESY  
LIGHT SWITCH LH

TRANSPONDER KEY ECU

UNLOCK WARNING SWITCH



ECM

SECURITY INDICATOR

TRANSPONDER KEY AMPLIFIER

MAIN BODY ECU

(DRIVER SIDE JUNCTION BLOCK)

- IGN FUSE

DLC3

