


Last Modified: 9-13-2007		1.6 A
Service Category: Vehicle Interior	Section: Power Outlets (int)	
Model Year: 2008	Model: FJ Cruiser	Doc ID: RM0000026Y0001X
Title: OTHER SYSTEM: VOLTAGE INVERTER: REMOVAL (2008 FJ Cruiser)		

## REMOVAL

1. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL
2. REMOVE REAR SEAT BACK BOARD CARPET ASSEMBLY RH [INFO](#)
3. REMOVE REAR SEATBACK ASSEMBLY RH [INFO](#)
4. REMOVE REAR FLOOR BOARD [INFO](#)
5. REMOVE REAR FLOOR MAT SUPPORT PLATE [INFO](#)
6. REMOVE REAR FLOOR MAT ASSEMBLY [INFO](#)
7. REMOVE FRONT DOOR SCUFF PLATE RH [INFO](#)
8. REMOVE REAR DOOR SCUFF PLATE RH [INFO](#)
9. REMOVE PACKAGE HOLDER NET HOOK (w/o Amplifier Box Speaker Assembly) [INFO](#)
10. REMOVE QUARTER TRIM POCKET TRAY (w/o Amplifier Box Speaker Assembly) [INFO](#)
11. REMOVE SIDE TRIM COVER (w/o Amplifier Box Speaker Assembly) [INFO](#)
12. REMOVE QUARTER TRIM POCKET (w/o Amplifier Box Speaker Assembly) [INFO](#)
13. REMOVE DECK SIDE GARNISH (w/ Amplifier Box Speaker Assembly) [INFO](#)
14. REMOVE SPEAKER MOUNTING COVER (w/ Amplifier Box Speaker Assembly) [INFO](#)
15. REMOVE AMPLIFIER BOX SPEAKER ASSEMBLY (w/ Amplifier Box Speaker Assembly) [INFO](#)
16. REMOVE LAP BELT OUTER ANCHOR COVER [INFO](#)
17. REMOVE REAR SEAT OUTER BELT ASSEMBLY RH [INFO](#)
18. REMOVE DECK TRIM SIDE PANEL ASSEMBLY RH [INFO](#)




### 19. REMOVE VOLTAGE INVERTER ASSEMBLY



(a) Remove the bolt and the earth wire.

(b) Disconnect the 2 connectors and the wire harness clamp.



(c) Remove the 5 bolts and remove the voltage inverter assembly.

