

PROBLEM SYMPTOMS TABLE

HINT:

Use the table below to determine the cause of the problem symptom. The potential causes of the symptom are listed in order of probability in the "Suspected Area" column of the table. Check each symptom by checking the suspected areas in the order they are listed. Replace parts as necessary.

Audio Function

Symptom	Suspected area	See page
Noise occurs	1. Proceed to Noise Occurs	AV-14
	2. Radio Receiver	-
Pressing power switch does not turn on system	1. Proceed to Pressing Power Switch does not Turn on System	AV-15
	2. Proceed to Radio Receiver Power Source Circuit	AV-49
	3. Radio Receiver	-
No sound can be heard from speakers (audio is mute)	1. Proceed to No Sound can be Heard from Speakers (Audio is Mute)	AV-16
	2. Proceed to Speaker Circuit	AV-35
	3. Proceed to Radio Receiver Power Source Circuit	AV-49
	4. Proceed to Woofer Speaker Power Source Circuit (w/ woofer speaker)	AV-46
	5. Radio Receiver	-
Sound quality is bad only when CD is played (volume is too low)	1. Proceed to Sound Quality is Bad Only when CD is played (Volume is too low)	AV-17
	2. Proceed to Speaker Circuit	AV-35
	3. Proceed to Woofer Speaker Power Source Circuit (w/ woofer speaker)	AV-51
	4. Radio Receiver	-
CD cannot be ejected	1. Proceed to CD cannot be Ejected	AV-18
	2. Proceed to Radio Receiver Power Source Circuit	AV-49
	3. Radio Receiver	-
CD cannot be inserted / played or CD is ejected right after insertion	1. Proceed to CD cannot be Inserted / Played or CD is Ejected Right After Insertion	AV-19
	2. Proceed to Radio Receiver Power Source Circuit	AV-49
	3. Radio Receiver	-
CD sound skips	1. Proceed to CD Sound Skips	AV-21
	2. Radio Receiver	-
Radio broadcast cannot be received (bad reception)	1. Proceed to Radio Broadcast cannot be Received (Bad Reception)	AV-23
Poor sound quality in all modes (low volume)	1. Proceed to Poor Sound Quality in All Modes (Low Volume)	AV-25
	2. Proceed to Speaker Circuit	AV-35
	3. Radio Receiver	-
Radio receiver cannot be illuminated at night	1. Proceed to Illumination Circuit	AV-30
	2. Radio Receiver	-
External device sound cannot be heard or sound quality is bad. (Stereo jack is used.)	1. Proceed to Sound Signal Circuit between Radio Receiver and Stereo Jack Adapter	AV-43
	2. Stereo Jack Adapter	-
	3. Noise Filter	-
	4. Radio Receiver	-
Woofer system cannot be operated with woofer speaker switch (w/ woofer speaker)	1. Proceed to Woofer Speaker Switch Circuit	AV-46
	2. Radio Receiver	-
	3. Proceed to Woofer Speaker Power Source Circuit	AV-51

Steering Pad Switch Function

Symptom	Suspected area	See page
Audio system cannot be operated with steering pad switch	1. Proceed to Steering Pad Switch Circuit	AV-26
	2. Radio Receiver	-
Steering pad switch cannot be illuminated at night	1. Proceed to Illumination Circuit	AV-30
	2. Radio Receiver	-

AV